Sports AM/FM Pocket Radio
(120-0190) Preparation Faxback Doc. # 45303

AM/FM Pocket Radio Features include:

Water Resistant

Great AM/FM Sound

Built-In Speaker

Installing Batteries

Two AAA Batteries (Cat. No. 23-555)

1. Press the battery compartment cover tab in the direction of the arrow and remove the cover.

2. Install new batteries according to the polarity marks (+ and -) marked inside the battery compartment.

3. Reinstall the battery compartment cover and snap it into place.

CAUTIONS: Match the polarity symbols (+ and -) marked inside the battery compartment.

Always use fresh batteries of the required size and type.

Using The Radio

Notes: This radio is resistant to water damage. However, it is not waterproof and should not be submerged in water or put directly in front of shower spray.

The radio's antennas are built-in. For the best reception adjust the radio's position.

Controls:

AM/FM Switch:	Slide to select the band.
TUNING Knob:	Turn to select your favorite station.
VOLUME/OFF Knob:	Turn until you hear a click to turn the radio on and off; turn to adjust the volume.

FCC Statement

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn it off. If the interference goes away, your radio is causing it. Try to eliminate the interference by:

Moving your radio away from the receiver.

Contacting your local RadioShack store for help.

If you cannot eliminate the interference, the FCC requires that you stop using the radio.

Sports AM/FM Pocket Radio
(120-0190) Care and Maintenance Faxback Doc. # 45305

Caring for Your Radio

To enjoy your radio for a long time:

Handle it gently.

Keep it away from dust, moisture, and temperature extremes.

Clean it with a damp cloth. Do not use harsh chemicals.

Do not take it apart. If something is wrong with the radio, take it to your local RadioShack store for assistance.

Sports AM/FM Pocket Radio
(120-0190) Specifications Faxback Doc. # 45306

AM: ..... 530 - 1710 kHz

FM: ..... 88 - 108 MHz

Power Source: ..... 2 AAA Batteries (Cat. No. 23-555)

Dimensions (HWD): ..... 4-7/8 x 2-3/4 x 15/16 Inches

Weight: ..... 4.2 oz. (Without Batteries)

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

(EB 11/7/97)
LN-03/04